yutong bus parts catalog

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Primary Fuel Filter	1101-03160	ZK6126HGA
Primary Fuel Filter	1105-00431	ZK6126HGA
Primary Fuel Filter	1105-00420	ZK6126HGA
Oil Filter	1000-00524	ZK6126HGA
Fuel Pressure Sensor	3612-00017	ZK6126HGA
Flow meter Unit	3612-00025	ZK6126HGA
Multi-Wedge Belt	1025-00282	ZK6126HGA
Thermostat	1306-00517	ZK6126HGA
Oil Pressure/Temperature Sensor	3610-00063	ZK6126HGA
Intake Pressure Sensor	3611-00101	ZK6126HGA
Water Temperature Sensor	3611-00100	ZK6126HGA
Rotation Speed Sensor	3611-00099	ZK6126HGA
Starter	3708-00330	ZK6126HGA
Belt 15 * 1615 fan belt	9405-00346	ZK6126HGA
Duplex Btype Belt2/AV15x1805 Crank shaft belt	9405-00878	ZK6126HGA
Expansion Tank Pressure Cover;0.7MPa	1311-01116	ZK6126HGA
Expansion Tank Pressure Cover;1.0MPa	1311-01302	ZK6126HGA
Duplex B-type Belt	9601-05126	ZK6126HGA
Fuel Sensor	3731-00822	ZK6126HGA
Air Pressure Sensor	3731-00048	ZK6126HGA
Fault/Oil Temperature Indicator Lamp	3792-00607	ZK6126HGA
Air Filter Element	1109-06811	ZK6126HGA
Single-side Sealed Bearing (fan bearing)	1315-00127	ZK6126HGA
Non-contact, One-side Sealed Bearing	1315-00918	ZK6126HGA
Open-type Bearing	1315-00917	ZK6126HGA
Transmission Filter Element-Fine	1711-00049	ZK6126HGA
Filter Element-Oil Pan	1711-00024	ZK6126HGA
Transmission oil pan	1761-00415	ZK6126HGA
Brake Chamber	3519-00751	ZK6126HGA
Disk Brake Assy.-Left	3502-00685	ZK6126HGA
Brake Caliper -Left	3502-00192	ZK6126HGA
Brake Lining	3552-00429	ZK6126HGA
Disk Brake Assy.-Right	3502-00686	ZK6126HGA
Brake Caliper -Right	3502-00193	ZK6126HGA
Brake Disk	3501-01054	ZK6126HGA
Shock Absorber	2915-00391	ZK6126HGA
Air Spring assy.	2935-00913	ZK6126HGA
Air Spring	2935-00914	ZK6126HGA
Tie Rod Joint -Right	3003-00169	ZK6126HGA
Needle Bearing	2905-00679	ZK6126HGA
Inner Bearing, Front Wheel	3003-00164	ZK6126HGA
ABS Sensor	3550-00242	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Front Brake Disk	3501-00114	ZK6126HGA
Brake Disk	3501-00150	ZK6126HGA
Shock Absorber	3001-01487	ZK6126HGA
Air Spring assy.	2930-00651	ZK6126HGA
Air Spring	2930-00754	ZK6126HGA
Air Spring Base	2930-01075	ZK6126HGA
Front Brake Assy.	3000-01078-02	ZK6126HGA
Front Brake Chamber Assy.	3519-01000	ZK6126HGA
Right Disk Brake Assy.	3501-02497	ZK6126HGA
Brake Lining Repair Kit	3552-01127	ZK6126HGA
Brake caliper; L	3501-02478	ZK6126HGA
Left Disk Brake Assy.	3501-02498	ZK6126HGA
"BrakeDisk Assy.,Front Wheel Hub"	3503-00028	ZK6126HGA
Brake caliper; R	3501-02479	ZK6126HGA
Drag link ball joints	3412-00168	ZK6126HGA
Drag Link Joint-RH	3412-00169	ZK6126HGA
Steering Drive Shaft Assy.	3401-00389	ZK6126HGA
Angle Steering Gear Assy.	3415-00013	ZK6126HGA
Steering Oil Tank Filter Element	3408-00340	ZK6126HGA
ABS Solenoid Valve	3550-00017	ZK6126HGA
Air Drier	3529-00019	ZK6126HGA
Drier Repair Kit	3529-00034	ZK6126HGA
ECAS Solenoid Valve	3506-01075	ZK6126HGA
ECAS Solenoid Valve	3506-01316	ZK6126HGA
Side Turn Signal Lamp	4111-00037C	ZK6126HGA
Side Turn Signal Lamp	4111-00129	ZK6126HGA
Front Turn Signal Lamp	4116-00035	ZK6126HGA
High beam lamp	4101-00074	ZK6126HGA
low beam lamp	4101-00075	ZK6126HGA
Front Fog Lamp	3714-00002	ZK6126HGA
Rear Turn Signal Lamp	4111-00030	ZK6126HGA
Rear Multi-function Lamp	4107-00018	ZK6126HGA
Reversing Lamp	4113-00009	ZK6126HGA
Rear Fog Lamp	4116-00021	ZK6126HGA
Front Fog Lamp	3714-00002	ZK6126HGA
24V/21W	4101-00078	ZK6126HGA
Bulb		
Bulb,24/70W	4141-00049	ZK6126HGA
Multi function instrument	3820-02553	ZK6126HGA
Water level switch	3825-00009	ZK6126HGA
Air pressure sensor	3818-00048	ZK6126HGA
Ignition Switch	3704-00077	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Speedometer sensor mounting	3802-00374	ZK6126HGA
2-way High-Current Fuse	3722-01925	ZK6126HGA
Relay-CB1-M-24v.24V 20A	3731-00283	ZK6126HGA
Relay- CB1-24V 24V 20A	3731-00285	ZK6126HGA
Fuse,10A	9324-00005	ZK6126HGA
Fuse;5A	3722-00075	ZK6126HGA
Fuse;3A	3722-00074	ZK6126HGA
Fuse,15A	9324-00006	ZK6126HGA
Fuse;20A	3722-00960	ZK6126HGA
Fuse; 7.5	9324-00012	ZK6126HGA
Fuse;20A	3736-00034	ZK6126HGA
Fuse;20A	3722-00584	ZK6126HGA
Delay Relay	3731-00447	ZK6126HGA
Relay 896H-1CH-C-R1 M30 24V	3722-01092	ZK6126HGA
Wiper	5205-01870	ZK6126HGA
Combined Flashing Alarm	3735-00328	ZK6126HGA
Front Windshield Glass	5302-03948	ZK6126HGA
Right 6th Sliding Window assy.	5403-57179	ZK6126HGA
Right 4th Sliding Window Assy. 5th	5403-16137	ZK6126HGA
Right 4th Sliding Window Assy.	5403-57176	ZK6126HGA
Right 3rd Sliding Window Assy.	5403-57172	ZK6126HGA
Right 2nd Sliding Window Assy.	5403-57171	ZK6126HGA
Right 1st Sliding Window Assy.	5403-57149	ZK6126HGA
Right 1st Glass	5403-57199	ZK6126HGA
Left 2nd Glass	5403-57194	ZK6126HGA
Right 3rd Glass	5403-57201	ZK6126HGA
Left 1st Upper Sliding Window Assy.	5403-57127	ZK6126HGA
Left 2nd Glass	5403-57182	ZK6126HGA
Left 5th Sliding Window Assy.	5403-16130	ZK6126HGA
Rear Movable Glass (left 5th movable glass)	5403-16146	ZK6126HGA
Rear windshield glass	5602-03522	ZK6126HGA
Cylinder Assy.	6208-00869	ZK6126HGA
Front Service Door Toughened Glass	6103-01094	ZK6126HGA
Cylinder Assy.	6208-00869	ZK6126HGA
Middle Service Door Toughend Glass	6203-00448	ZK6126HGA
Middle Service Door Toughend Glass	6203-00454	ZK6126HGA
Crankshaft Belt Pulley	1005-00882	ZK6126HGA
Pressure Sensor	2111-00019	ZK6126HGA
Fuel Filter assy.	1105-00538	ZK6126HGA
Primary Fuel Filter Element	1012-00565	ZK6126HGA
Water Sensor	3614-00108	ZK6126HGA
Water cup	1105-00174	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Thermostat	1306-00517	ZK6126HGA
B-type Toothed Belt -1645	9405-00337	ZK6126HGA
Duplex B-type Belt	9405-02353	ZK6126HGA
EM Clutch,Fan	1314-00265	ZK6126HGA
Drive Shaft Spider	2201-01536	ZK6126HGA
Brake Caliper-Right	3501-02589	ZK6126HGA
Brake Caliper-left	3501-02588	ZK6126HGA
Air Spring	2930-00754	ZK6126HGA
Rear Brake Chamber Assy	3519-01002	ZK6126HGA
Disk caliper Assy.-Left	3502-01426	ZK6126HGA
Disk caliper Assy.-right	3502-01425	ZK6126HGA
Air Spring (Rear)	2935-00914	ZK6126HGA
Steering Drag Link	3422-00890	ZK6126HGA
Drag Link Joint -Left	3422-00967	ZK6126HGA
Drag Link Joint -right	3422-00968	ZK6126HGA
Accelerator Pedal Sensor	3614-00079	ZK6126HGA
Bulb,24/70W	4141-00049	ZK6126HGA
Bulb	4141-00036	ZK6126HGA
Bulb; 24V/21W	4141-00050	ZK6126HGA
Bulb	4104-00061	ZK6126HGA
Lamp Shade	4107-00027	ZK6126HGA
Rear Fog Lamp	4116-00021A	ZK6126HGA
Bulb	4100-00160	ZK6126HGA
Front Service Door Toughened Glass	6103-01094	ZK6126HGA
Middle Service Door Toughened Glass	6203-00454	ZK6126HGA
Rear Windshield Glass	5602-11352	ZK6126HGA
Differential Relay Valve	3527-00021	ZK6126HGA
Front Windshield Glass	5302-03948	ZK6126HGA
Rear Movable Glass (left 5th movable glass)	5403-16146	ZK6126HGA
Driver Window Front Movable Glass	6403-02845	ZK6126HGA
Driver Window Rear Movable Glass	6403-02846	ZK6126HGA
Oil Filter	1000-00524	ZK6126HGA
Water filter element	1105-00245	ZK6126HGA
Primary fuel filter	1105-00147	ZK6126HGA
Filter Element,Fuel,Fine (China)"	1117-00079	ZK6126HGA
Oil Pressure/Temperature Sensor	3610-00063	ZK6126HGA
Starter	3708-00330	ZK6126HGA
Duplex B-type Belt	9601-05126	ZK6126HGA
Multi-wedge Belt	1025-00282	ZK6126HGA
Multi-wedge Belt	1025-00290	ZK6126HGA
Turbocharger	1118-00497	ZK6126HGA
Air compressor	3509-01128	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Common rail injection pump	1111-00567	ZK6126HGA
Radiator	1301-03699	ZK6126HGA
Front Hub Oil Seal	3103-01307	ZK6126HGA
ECU ECAS	3550-00643	ZK6126HGA
Generator	3701-01353	ZK6126HGA
Tie Rod Assy.	3003-03341	ZK6126HGA
Starter	1015-00053	ZK6126HGA
Fuel Injector	1112-00392	ZK6126HGA
Multi-function instrument	3820-02863	ZK6126HGA
Brake Lining	3552-01334	ZK6126HGA
Rear Brake Disk	3501-02216	ZK6126HGA
Brake Disk	3501-01054	ZK6126HGA
Tie Rod Joint-Right	3003-03227	ZK6126HGA
Front Brake Chamber Assy.	3519-01000	ZK6126HGA
Left Front Windshield Glass	5302-05126	ZK6126HGA
Right Front Windshield Glas	5302-05127	ZK6126HGA
Rotation speed sensor	3623-00177	ZK6126HGA
Right 6th Sliding Window assy.	5403-57179	ZK6126HGA
Left 5th Sliding Window	5403-16130	ZK6126HGA
Left 4th Sliding Window	5403-57139	ZK6126HGA
Left 2nd Sliding Window Assy.	5403-57133	ZK6126HGA
Upper front windshield	5302-05597	ZK6126HGA
Right 2nd Sliding Window Assy.	5403-57171	ZK6126HGA
Shock Absorber	2915-00697	ZK6126HGA
Transmission Filter Element-Fine	1711-00049	ZK6126HGA
Right 4th Sliding Window	5403-57176	ZK6126HGA
Right 3rd Sliding Window Assy.	5403-57172	ZK6126HGA
Left ABS Sensor	3550-00582	ZK6126HGA
Right ABS Sensor	3550-00583	ZK6126HGA
Wiper motor	3741-00039	ZK6126HGA
Right rear view mirror	8202-00380	ZK6126HGA
Left rear view mirror	8202-00379	ZK6126HGA
Rear windshield glass	5602-03522	ZK6126HGA
Low-beam Lamp	4101-00075	ZK6126HGA
3rd Brake Lamp Assy.	3716-00053A	ZK6126HGA
Water pump	1307-00811	ZK6126HGA
Height sensor	3506-05675	ZK6126HGA
Air Filter Element	1109-06811	ZK6126HGA
King pin	3005-00220	ZK6126HGA
High-beam Lamp	4101-00074	ZK6126HGA
Thermostat	1306-00745	ZK6126HGA
Wiper linkage	5205-01877	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Backup Lamp	4113-00024	ZK6126HGA
ABS Sensor	3550-00242	ZK6126HGA
Intake pressure sensor	3611-004312	ZK6126HGA
Oil pressure sensor	3611-00432	ZK6126HGA
Front Fog Lamp	3714-00002A	ZK6126HGA
Drier Filter Element	3529-00033	ZK6126HGA
Rear Multi-function Lamp	4107-00018A	ZK6126HGA
Right 1st Glass	5403-57199	ZK6126HGA
Left 2nd Glass	5403-57194	ZK6126HGA
Rear Turn Signal Lamp	4111-00030A	ZK6126HGA
Wiper arm left	5205-01884	ZK6126HGA
Wiper arm Right	5205-01886	ZK6126HGA
Right 4th Glass	5403-57202	ZK6126HGA
Fuel Filter	1117-00181	ZK6126HGA
Oil Filter Element(China)	1012-00146	ZK6126HGA
Right 1st Glass	5403-57190	ZK6126HGA
Glass above Rear Door	5403-11066	ZK6126HGA
Right 3rd glass	5403-57200	ZK6126HGA
Left 5th Window Upper Closed Glass	5403-19028	ZK6126HGA
Multi-wedge Belt	9405-00676	ZK6126HGA
Front Turn Signal Lamp	4116-00035A	ZK6126HGA
Left 7th Glass	5403-57188	ZK6126HGA
Left 3rd Glasss	5403-57184	ZK6126HGA
Wiper Blade	5205-01881	ZK6126HGA
Fuel Filter	1117-00182	ZK6126HGA
Left 5th Glass	5403-57187	ZK6126HGA
Water temperature sensor	3611-00504	ZK6126HGA
License Plate Lamp Assy.	3715-00034A	ZK6126HGA
Right Headlamp Side Trim Panel	4101-00054	ZK6126HGA
Left Headlamp Side Trim Panel	4101-00053	ZK6126HGA
Rear Marker Lamp	3716-00238	ZK6126HGA
Air Filter Element	1109-03726	ZK6126HGA
Oil Filter	1000-00524	ZK6126HGA
security filter	A1109-14100010	ZK6126HGA
Air Filter Element	1109-03624	ZK6126HGA
Water filter Assembly	6100-05639	ZK6126HGA
REAR RIGHT DECORATIVE	A3780-02100157	ZK6126HGA
ECAS SOLENAID VALVE	3506-01326	ZK6126HGA
RIGHT ANGLE RUBBER HOSE	1109-03600	ZK6126HGA
SERVICE OF DOOR ELECTRIC VALVE	6100-06161	ZK6126HGA
WHEEL NUT	A3000-00100569	ZK6126HGA
SEALING BEARING	A1308-00100054 G.B	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
NATRAW BELT	A1308-31100097	ZK6126HGA
STRAIGHT STEEL PIPE	A1303-02178	ZK6126HGA
OIL COOLING INTER PIPE	A1303-22100429	ZK6126HGA
RETURY OIL STEEL PIPE	3406-13100303	ZK6126HGA
FUEL TANK CUP	A1101-12100071	ZK6126HGA
INTER COOLER INTAKE PIPE	1303-01982	ZK6126HGA
L-HOSE	A1109-2110317	ZK6126HGA
INTAKE RUBBER HOSE	1109-03601	ZK6126HGA
L-STEEL PIPE	1109-06266	ZK6126HGA
L-STEEL PIPE	1303-04908	ZK6126HGA
AIR INTAKE HOSE	A1109-21100316	ZK6126HGA
AIR INTAKE HOSE	A1109-2110017	ZK6126HGA
TRANSMISSION OIL COOLED PIPE	A1303-22100432	ZK6126HGA
FORWAY CIVE OUTER PRO VALUE	A3506-23100001	ZK6126HGA
POLYURE THAN HOSE	3406-00948	ZK6126HGA
Expansion tank fulling pipe	A1303-23100596	ZK6126HGA
CONCTING STEERIGHT PIPE	A1101-28100003	ZK6126HGA
BRACK CABLE HOSE	A3406-13100306	ZK6126HGA
DOOR CYLINDER	A6100-00100159	ZK6126HGA
CUT OF VALVE	R3506-00000289	ZK6126HGA
FUEL TANK COVER	1103-00028	ZK6126HGA
DRIVE SHEFT	2201-00971	ZK6126HGA
BRAKE LINING	3552-00429	ZK6126HGA
DEFORESTER	8102-00930	ZK6126HGA
WHEEL NUT	9601-01351	ZK6126HGA
ECANS SALONAID VALVE	3506-01316	ZK6126HGA
WHEEL BOLT M 22*1.5*66 10.9	3501-00851	ZK6126HGA
ECANS SALONAID VALVE	3506-01075	ZK6126HGA
720 FAN CAWL	1309-00063	ZK6126HGA
700, 64 , FAN	1308-00457	ZK6126HGA
21W. 24V BULB	4107-0024	ZK6126HGA
R.S.W BOLD	3755-00026	ZK6126HGA
MIDDLE PULLEY SUB ASSY	1315-00895	ZK6126HGA
SHOCK ABSORBER ASSY	2901-00414	ZK6126HGA
FUEL SENSOR	3731-00330	ZK6126HGA
ELECTRIC HORN	3721-00034	ZK6126HGA
ELECTRIC HORN	3721-00035	ZK6126HGA
S.P.00058738 LOUD SPEAKER	7903-00042	ZK6126HGA
L.E.D.OUT DOORSPOT LAMP	4112-00013	ZK6126HGA
HAND BRAKE VALVE	3526-00006	ZK6126HGA
INGNITION SWITCH	3704-00077	ZK6126HGA
REAR WINDOW SHIELD GLASS	5602-03522	ZK6126HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
LEFT LAST GLASS	5403-57203	ZK6126HGA
LEFT 7TH GLASS	5403-57198	ZK6126HGA
LEFT 5TH GLASS	5403-57197	ZK6126HGA
LEFT 3RD GLASS	5403-57195	ZK6126HGA
RIGHT FIRST GLASS	5403-57199	ZK6126HGA
LEFT 1ST GLASS	5403-57193	ZK6126HGA
LEFT 4TH GLASS	5403-57196	ZK6126HGA
RIGHT LAST GLASS	5403-57208	ZK6126HGA
DRIVEN WINDOW LOWER FIXED GLASS	6403-01952	ZK6126HGA
LEFT 3RD GLASS	5403-25998	ZK6126HGA
LEFT 5TH MONABLE GLASS	5403-16146	ZK6126HGA
LEFT 5TH SLIDING WINDOW	5403-16130	ZK6126HGA
HGB LEFT 1ST UPPER SLIDING WINDOW	5403-57127	ZK6126HGA
RIGHT 2ND SLIDING WINDOW	5403-57171	ZK6126HGA
RIGHT 1ST SLIDING WINDOW	5403-57149	ZK6126HGA
FRONT WIND SHIELD GLASS	5302-03948	ZK6126HGA
AIR DRIER FILTER ELEMENT	3529-00033	ZK6126HGA
BULB 24 V 21 W	4141-00031	ZK6126HGA
THERMOSTAT	612600061748/1306-00517	ZK6126HGA
STARTER	612600091076/3708-00330	ZK6126HGA
REAR CLOSED ELECTRICAL BOX	3722-01812	ZK6126HGA
SHOCK ABSORBER	2915-00391	ZK6126HGA
STEERING LOW PRESSURE OIL PIPE	3406-01858	ZK6126HGA
NS ADJUSING BOLT	10X2X2CM 1315-00457	ZK6126HGA
FRONT TURN SIGNAL LAMP	4116-00035	ZK6126HGA
MULTI FUNCTION SWITCH	3774-00001/3774-00056	ZK6126HGA
FLOW METER UNIT	928400617/3612-00025	ZK6126HGA
OIL PRESSURE/TEMPRATURE SENSOR	612600090460/3610-00063	ZK6126HGA
PRESSURE SWITCH	1710-00006	ZK6126HGA
CRANK SHIFT FRONT OIL SEAL	1005-00685	ZK6126HGA
HEIGHT SENSOR	441050010/3506-00211	ZK6126HGA
WATER CUP	1104-02452	ZK6126HGA
LEFT HEAD LAMP SHADE	5302-06229	ZK6126HGA
SHOCK ABSORBER RUBBER WASHER	2905-00306	ZK6126HGA
RIGHT HEAD LAMP SHADE	5302-06230	ZK6126HGA
STEERING OIL TANK FILTER	3408-00340	ZK6126HGA
WATER FILTER ELEMENT	612600081294/1105-00245	ZK6126HGA
FILTER ELEMENT,FUEL,FINE	1000422382/1117-00079	ZK6126HGA
CONDENSER	3506-04879	ZK6126HGA
Oil Pump Assy.	1011-00220	ZK6118HGA
connecting rod bolt	1004-00360	ZK6118HGA
cylinder head hood gasket	1003-00291	ZK6118HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Cylinder Head Gasket	1003-00395	ZK6118HGA
Piston ring	1004-00370	ZK6118HGA
Piston	1004-00835	ZK6118HGA
connecting rod bearing	1004-01140	ZK6118HGA
Connecting rod Ass	1000-00514	ZK6118HGA
Crankshaft Front Oil Seal	1005-00685	ZK6118HGA
Sealing Ring	1002-00633	ZK6118HGA
Primary fuel filter	1101-03160	ZK6118HGA
Diesel fine fuel filter Assy	1025-00066	ZK6118HGA
Fuel filter Assy	1105-00420	ZK6118HGA
oil filter	1000-00524	ZK6118HGA
Fuel Injector Assy	1112-00157	ZK6118HGA
Limit Valve	1128-00231	ZK6118HGA
Fuel Pressure Sensor	3612-00017	ZK6118HGA
Crankshaft Rear Oil Seal	1005-00686	ZK6118HGA
turbocharger	1118-00497	ZK6118HGA
Multi-wedge Belt	1025-00282	ZK6118HGA
Water Pump Assy.	1307-00330	ZK6118HGA
Air filter (Air cleaner)	1109-01400	ZK6118HGA
air filter clogging alarm	3819-00023	ZK6118HGA
Radiator Assy	1301-03676	ZK6118HGA
Open-type Bearing	1315-00917	ZK6118HGA
pressure sealing cup,water filler	1311-00940	ZK6118HGA
Main Bearing Bush	1005-02120	ZK6118HGA
cam shaft sleeve	1006-00066	ZK6118HGA
Thrust Washer	1005-01929	ZK6118HGA
cam shaft sleeve	1006-00179	ZK6118HGA
Cylinder Liner	1002-00415	ZK6118HGA
oil cooler shim	1013-00062	ZK6118HGA
Oil Pan Shim	1009-00095	ZK6118HGA
Pressure Sealing Cap, Water Filler,38mm,100kPa	1311-00940	ZK6118HGA
Belte Pully	1315-00693	ZK6118HGA
Push rod	1007-01535	ZK6118HGA
intake valve	1007-00373	ZK6118HGA
Intake pipe shim	1008-00283	ZK6118HGA
exaust valve	1007-00388	ZK6118HGA
valve stem sealing sleeve	1007-00633	ZK6118HGA
valve cap	1007-01201	ZK6118HGA
water Pump gasket	1000-00537	ZK6118HGA
Flow meter unit	3612-00025	ZK6118HGA
oil pan gasket	1701-11332	ZK6118HGA
electronic control unit	3610-00038	ZK6118HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
ABS Sensor	3550-00182	ZK6118HGA
Wear Indicator Sensor Repair Kit	3501-00570	ZK6118HGA
Wear Sensor Repair Kit	3501-01931	ZK6118HGA
Air Spring Subassy.	2931-00150	ZK6118HGA
ABS Sensor	3550-00254	ZK6118HGA
Friction Lining (249.9*118*29)	3552-00741	ZK6118HGA
Wear Sensor	3629-00015	ZK6118HGA
Needle Bearing(50*58*25)	9401-05817	ZK6118HGA
Inner Bearing, Rear Wheel Hub"(95*152*39.7)	3103-00666	ZK6118HGA
Rear Wheel Hub Oil Seal(121*161*2.86)	3104-00216	ZK6118HGA
Outer Bearing, Wheel Hub"	3104-01130	ZK6118HGA
ABS Solenoid Valve	3550-00017	ZK6118HGA
Air drier	3529-00019	ZK6118HGA
Drayer filter element	3529-00033	ZK6118HGA
Drayer repair kit	3529-00034	ZK6118HGA
Electric control press, Brake valve	3514-00153	ZK6118HGA
Accelerator Pedal Position Sensor	3514-00153	ZK6118HGA
Side Turn Signal Lamp	4111-00037C	ZK6118HGA
Rear Turn Signal Lamp	4111-00030	ZK6118HGA
Reversing Lamp	4113-00009	ZK6118HGA
Front Turn Signal Lamp	4116-00035	ZK6118HGA
High beam lamp	4101-00074	ZK6118HGA
low beam lamp	4101-00075	ZK6118HGA
Oil Pressure/Temperature Sensor	3610-00063	ZK6118HGA
Transition joint air sensor	3611-00031	ZK6118HGA
Rotational speed sensor	3611-00099	ZK6118HGA
Intake Pressure Sensor	3611-00101	ZK6118HGA
Water Temperature Sensor	3611-00100	ZK6118HGA
Air pressure brake lamp switch	3712-00098	ZK6118HGA
Front Fog Lamp	3714-00002	ZK6118HGA
rocker arm	1007-00992	ZK6118HGA
24V/21W Bulb	4101-00078	ZK6118HGA
Speedometer sensor mounting	3802-00374	ZK6118HGA
Air pressure sensor	3818-00048	ZK6118HGA
Multi function instrument	3820-02440	ZK6118HGA
Water level switch	3825-00009	ZK6118HGA
Sensor harness	4001-01389	ZK6118HGA
Front Windshield Glass	5302-02469	ZK6118HGA
left 5th lower closed glass	5403-62215	ZK6118HGA
closed glass	5403-67788	ZK6118HGA
Left 1st Lower Slide Assy	5403-10137	ZK6118HGA
Left 2nd Lower Sliding Window Assy	5403-18258	ZK6118HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Left 2nd Lower Sliding Window Assy	5403-10138	ZK6118HGA
Rear view Mirror	8202-04106	ZK6118HGA
sealing ring air compressor	3509-00646	ZK6118HGA
Gasket	1303-04316	ZK6118HGA
Intercooler Assy.	1119-00493	ZK6118HGA
Fuel Tank Cover	1101-06085	ZK6118HGA
B- type Toothed V-beltpes	9304-00454-	ZK6118HGA
B-type toothed V-belt	9405-00345	ZK6118HGA
B-type Toothed V-belt	9405-00368	ZK6118HGA
Duplex B-type belt	9405-00930	ZK6118HGA
double x B-type belt	9405-00933	ZK6118HGA
Duplex B-type Belt	9405-00942	ZK6118HGA
Fan , Φ700,Φ64	1308-00457	ZK6118HGA
single side seald bearing	1315-00127	ZK6118HGA
Expansion Tank Cover;70Kpa	1311-00781	ZK6118HGA
Pressure Sealing Cap, Water Filler, 38mm,100kPa	1311-00940	ZK6118HGA
Sight Tube, Expansion Tank	1311-00844	ZK6118HGA
Pressure Switch	1710-00006	ZK6118HGA
Selector Switch	1504-00006	ZK6118HGA
Filter Element-Oil Pan	1711-00024	ZK6118HGA
Drive Shaft Flange Fork	2214-00087	ZK6118HGA
Spider	2214-00100	ZK6118HGA
Drive Shaft Flange Fork	2214-00055	ZK6118HGA
Shock Absorber Assy	2905-00918	ZK6118HGA
air-spring	2931-00442	ZK6118HGA
Shock Absorber Assy	2915-00489	ZK6118HGA
Hex-head Bolt，M16*45	9401-08657	ZK6118HGA
Hexagon Head Flange Bolts,M16*90	9401-08316	ZK6118HGA
Rear Brake Chamber Assy.-Right	3519-00817	ZK6118HGA
Rear Brake Chamber Assy.-Left	3519-00816	ZK6118HGA
Left Brake Caliper Assy.	3552-00742	ZK6118HGA
Right Brake Caliper Assy.	3552-00743	ZK6118HGA
disk brake assy.	3501-01137	ZK6118HGA
front wheel hub brake disk assy.	3503-00109	ZK6118HGA
Brake Caliper -Left	3501-01001	ZK6118HGA
Brake Caliper -right	3501-01002	ZK6118HGA
Wear Sensor	3629-00015	ZK6118HGA
Friction Lining Retaining Spring	3552-00808	ZK6118HGA
Friction Lining(249.9*118*29)	3552-00741	ZK6118HGA
Steering Oil Tank Filter Element	3408-00497	ZK6118HGA
Ignition Switch	3402-00460	ZK6118HGA
Wiper Blade	5205-00769	ZK6118HGA

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Starter	3708-00330	ZK6118HGA
Air valve	3101-00560	ZK6118HGA
cylinder	6208-0043	ZK6118HGA
Rear Cylinder	6208-00433	ZK6118HGA
closed glass(front passenger door)	6103-01873	ZK6118HGA
Accelerator pedal positra sensor	1108-00697	ZK6118HGA
door cilinder	6204-00556	ZK6118HGA
flexible tube	3506-05112	ZK6118HGA
Fuel Pump Assy	1123-00009	ZK6116HGS
Air Compressor	1007-01147	ZK6116HGS
Belt Tensioner	9405-00418	ZK6116HGS
Fan Bracket	1308-00468	ZK6116HGS
Water Pump	1307-00112	ZK6116HGS
O-Ring Water Pump	1307-00088	ZK6116HGS
Oil Pan Gasket	1009-00064	ZK6116HGS
Oil Pan plug	1009-00079	ZK6116HGS
Washer /for Oil Pun Plug/	1005-00273	ZK6116HGS
Intaake Pressure Sensor	3611-00431	ZK6116HGS
Position Sensort -camshaft	3611-00271	ZK6116HGS
Pressure Sensor	3611-00274	ZK6116HGS
Air Filter element (air cleaner)	1109-01278	ZK6116HGS
Intercooler Assy	1119-00493	ZK6116HGS
Primary Fuel Filter Element	1101-05086	ZK6116HGS
Primary Fuel Filter assy.	1101-04947	ZK6116HGS
Radiator Assy	1301-03676	ZK6116HGS
Fan	1308-00458	ZK6116HGS
Expansion Tank	1311-01423	ZK6116HGS
Fuel Filter	1117-00181	ZK6116HGS
Fuel Filter 2nd	1117-00182	ZK6116HGS
oil filter	1012-00146	ZK6116HGS
Selector Switch	1504-00007	ZK6116HGS
Tie Rod Joint -Left (3003-00453)	3003-00168	ZK6116HGS
Tie Rod Joint -Right (3003-00454)	3003-00169	ZK6116HGS
Steering Knuckle	3001-00889	ZK6116HGS
King Pin	3001-00514	ZK6116HGS
King Pin Sealing Ring	3001-00932	ZK6116HGS
Needle Bearing	2905-00679	ZK6116HGS
King Pin Oil Seal	3001-00876	ZK6116HGS
King Pin Bushing	3001-00517	ZK6116HGS
Outer Bearing, Front Wheel	3003-00165	ZK6116HGS
Front Wheel Hub	3003-00167	ZK6116HGS
Inner Bearing, Front Wheel	3003-00164	ZK6116HGS

DESCRIPTION	PART NUMBER	Yutong bus MODEL
O-Ring 70*7	3003-00287	ZK6116HGS
ABS Bushing	3550-00243	ZK6116HGS
ABS Sensor	3550-00242	ZK6116HGS
Brake Disk	3501-00150	ZK6116HGS
Tie Rod Joint -Left	3003-00168	ZK6116HGS
Air Spring assy	2930-00651	ZK6116HGS
Air Spring	2930-00754	ZK6116HGS
Air Spring Bracket	2930-00800	ZK6116HGS
Air Spring Bracket	2930-00799	ZK6116HGS
disc brake assy - Left	3501-02498	ZK6116HGS
Disk Brake Assy.-Right	3501-02497	ZK6116HGS
Brake Caliper Bracket	3501-02480	ZK6116HGS
Brake Lining Repair Kit	3552-01127	ZK6116HGS
Wear Indication Sensor	3629-00005	ZK6116HGS
Wear Indication Sensor	3629-00004	ZK6116HGS
Brake caliper; R	3501-02479	ZK6116HGS
Brake caliper; L	3501-02478	ZK6116HGS
Conical Roller Bearing	3103-00301	ZK6116HGS
O ring	2403-01760	ZK6116HGS
Outer Bearing, Differential	2403-01721	ZK6116HGS
Lock Screw	9401-05426	ZK6116HGS
Left ABS Sensor	3550-00582	ZK6116HGS
Wear Indication Sensor	3629-00005	ZK6116HGS
Wear Indication Sensor	3629-00004	ZK6116HGS
Brake Lining	3552-00429	ZK6116HGS
Brake Caliper -Right	3502-00193	ZK6116HGS
Disk Brake Assy.-Left	3502-00685	ZK6116HGS
Brake Pad Pressure Plate -Left	3502-00218	ZK6116HGS
Brake Caliper -Left	3502-00192	ZK6116HGS
Air Spring	2935-00913	ZK6116HGS
Air Spring	2935-00914	ZK6116HGS
Air Spring Seat	2931-00961	ZK6116HGS
Shock Absorber	2915-00391	ZK6116HGS
Drag Link Ball Joint	3412-00168	ZK6116HGS
Drag Link Ball Joint- RH	3412-00169	ZK6116HGS
ASR Solenoid Valve	3506-00563	ZK6116HGS
Duplex check valve	3506-00565	ZK6116HGS
Air Drier	3529-00019	ZK6116HGS
Accelerator Pedal Sensor	3614-00079	ZK6116HGS
Side Turn Signal Lamp	3716-00180C	ZK6116HGS
Reversing Lamp	4113-00009A	ZK6116HGS
Fuse;200A/200A	3722-01403	ZK6116HGS

DESCRIPTION	PART NUMBER	Yutong bus MODEL
Fuel Sensor	3731-00820	ZK6116HGS
Combined Flashing Alarm	3735-00328	ZK6116HGS
Water Level Switch	3825-00009	ZK6116HGS
Air Pressure Sensor	3818-00048	ZK6116HGS
Fuse;200A	9324-00080	ZK6116HGS
Relay	3722-01298	ZK6116HGS
Relay	3731-00285	ZK6116HGS
Fuse,10A	9324-00108	ZK6116HGS
Fuse,15A	9324-00107	ZK6116HGS
Fuse; 7.5A	9324-00109	ZK6116HGS
Fuse;30A	9324-00112	ZK6116HGS
Fuse;5A	9324-00110	ZK6116HGS
Fuse;20A	9324-00111	ZK6116HGS
Fuse，100A/L	3722-01742	ZK6116HGS
Fuse;30A	3722-01738	ZK6116HGS
Fuse;40A	3722-01739	ZK6116HGS
Fuse，200A/K	3722-01737	ZK6116HGS
Fuse;150A	3722-01736	ZK6116HGS
Relay	3722-01092	ZK6116HGS
Delay Relay	3731-00447	ZK6116HGS
Fuse;3A	3722-00074	ZK6116HGS
Wiper Intermittent Controller	3731-00160	ZK6116HGS
Fuse;20A	3722-00960	ZK6116HGS
Wiper Blade-L	5205-01323	ZK6116HGS
Wiper Blade-R	5205-01324	ZK6116HGS
Front Lower Windshield Glass	5302-07660	ZK6116HGS
Left 2th upper Sliding Window	5403-65020	ZK6116HGS
Left 1st Glass	5403-33497	ZK6116HGS
Right 2th upper Sliding Window	5403-65021	ZK6116HGS
Rear Glass, Right Front Door"	5403-33502	ZK6116HGS
Right Last Lower Sliding Window Assy.	5403-65043	ZK6116HGS
Al. Sliding Window, Driver Window	6403-02522	ZK6116HGS
Front Toughened Glass, Front Door	6103-01000	ZK6116HGS
Rear Toughened Glass, Front Door	6103-01001	ZK6116HGS
Middle Service Door Toughened Glass	6203-00416	ZK6116HGS
Rearview Mirror Assy. -Left	8202-04271	ZK6116HGS
Rearview Mirror Assy. -Right	8202-04272	ZK6116HGS
fuel filter base	1101-06746	ZK6116HGS
water sensor	3614-00108	ZK6116HGS
B-type toothed V-belt	9405-00368	ZK6116HGS
DUPLEX B-type	9405-00942	ZK6116HGS
Multi-wedge belt	9405-00676	ZK6116HGS

DESCRIPTION	PART NUMBER	Yutong bus MODEL
multi-wedge belt	9405-01034	ZK6116HGS
multi-functional instrument	3820-02553	ZK6116HGS
Rectangle Washer	1002-00082	ZK6116HGS
Cylinder Liner	1002-01552	ZK6116HGS
Intake Valve	1007-01413	ZK6116HGS
Exhaust Valve	1007-01483	ZK6116HGS
Exhaust Valve Seat Ring	1007-01484	ZK6116HGS
Intake Valve Seat Race	1007-01485	ZK6116HGS
piston Ring	1004-01256	ZK6116HGS
piston Pin Retainer Ring	1005-00271	ZK6116HGS
Piston	1004-01257	ZK6116HGS
Connecting Rod	1004-00826	ZK6116HGS
Connecting Rod Bush	1004-01332	ZK6116HGS
Main Bearing Bush	1005-02148	ZK6116HGS
Connecting Rod Sleeve	1004-00730	ZK6116HGS
Brake Valve	3514-00046	ZK6116HGS
Relay Valve	3527-00042	ZK6116HGS
Drag Link Joint-LH	3412-00168	ZK6116HGS
Drag Link Joint-RH	3412-00169	ZK6116HGS
Front Upper Windshield Glass	5302-03887	ZK6116HGS
Turbocharger	1118-00943	ZK6116HGS
Air compressor	3509-00279	ZK6116HGS
Injector nozzle	1112-00295	ZK6116HGS
fuel filter primary	1117-00181	ZK6116HGS
fuel filter	1117-00182	ZK6116HGS
drier filter	3529-00033	ZK6116HGS
LEFT LAST LOWER SLIDING	5403-65042	ZK6116HGS
RIGHT 3TH LOWER SLIDING	5403-65075	ZK6116HGS
RIGHT 2TH LOWER SLIDING	5403-65083	ZK6116HGS
LEFT 1ST UPPER SLIDING WINDOW	5403-65036	ZK6116HGS
LEFT 4TH LOWER SLIDING WINDOW	5403-65039	ZK6116HGS
RIGHT LAST UPPER SLIDING	5403-65027	ZK6116HGS
LEFT LAST UPPER SLIDING	5403-65026	ZK6116HGS
HGS LEFT 3TH LOWER SLIDING WINDOW	5403-65065	ZK6116HGS
HGS RIGHT 1ST UPPER SLIDING	5403-65037	ZK6116HGS
EXPANSION TANK	1311-01423	ZK6116HGS
OILPAN GASUET	C3938/60/1009-00064	ZK6116HGS
WATER PUMP	C4934058/1307-00112	ZK6116HGS
CYLINDER GASKET	C4937728/1003-00529	ZK6116HGS
AUTOMATIC WATER DRAIN VALVE	3513-00141	ZK6116HGS
OIL FILTER	LF9009/1012-00146	ZK6116HGS
PRIMARY FUEL FILTER	YT05086/1101-04947	ZK6116HGS

DESCRIPTION	PART NUMBER	Yutong bus MODEL
CONDENSER	3506-04879	ZK6116HGS